







Tools: (Not supplied by manufacturer)

- Tape Measure
- Utility Knife
- Drill
- Caulk Gun
- Level
- Hammer
- Putty Knife
- Safety Glasses
- Square
- Hand Roller
- Foam Gun

Supplies: (Not supplied by Manufacturer)

- 9" flashing tape
- Sealant
- Low expanding Foam
- Non-biodegradable shims
- Fasteners
- Nail fin (if applicable)
- Chevrons (if applicable)



Cut the self-adhesive flashing tape to size using the formula provided above. If 9" flash tape is not being used, formulas will need to be adjusted. 9" is the minimum width permitted.

At the bottom left corner of the opening come down 9" and out 9"; mark this spot and repeat for the bottom right corner.

Apply your pre-cut sill flashing tape starting at the one of the predetermined spots made in the previous step and end at the other pre-marked spot. The flashing tape should touch both marks and reach up to the outside bottom of the rough opening. (

Step Two: *Window installation*

Remove packaging from the replacement window using utility knife making sure not to cut or damage interior or exterior frame/sash areas or screen.

If applicable, apply loose nail fin flange to all four sides of the window frame. (Fig. 0-

Apply the left side and right side flashing tape. Each piece should extend 8.5" above the head of the window and set 1/2" above the bottom of the sill flashing tape. (Fig. 2-2)

Use